

# AQUA FLEX W8



AQUA FLEX W8 is a two-component acrylic cementitious elastomeric waterproofing coating composed of highgrade liquid polymers, hydraulic binders, properly selected & graded aggregates, additives etc. The product is designed to waterproof structures like Swimming Pools, Bathrooms, Wash area, Balconies, Flower Beds, Water Tanks, Basements areas, Wet areas, Retaining Walls, Tunnels, Pile Heads, Fountain areas, Bridge deck etc. it can be easily applied on horizontal and vertical situations. On curing, this heavy-duty waterproofing component forms an elastomeric waterproof and protective layer to the substrate. It easy to use and can be applied by brush or roller.

# RECOMMENDED APPLICATION SUBSTRATE

Roofs

- Concrete Surfaces
- Water Tanks
- Basements Walls
- Masonry Surfaces
- Lift Pits

Balconies

Parking Decks

Podium

Terraces

- Swimming Pool
   Bathrooms
- Sunken Portions
- Toilets
- **BENEFITS & KEY FEATURES**
- Excellent barrier to carbon dioxide, chloride and sulphate ions.
- Allows water vapour to escape from the structure.
- Waterproof-suitable for water retaining structures.
- High resistance to the effect of long-term weathering.
- Durable in all climate conditions, including UV attack.
- Non-toxic ideal for potable water tanks.
- Flexible, with thermal expansion similar to concrete.
- Excellent bond to concrete and masonry.
- Good crack accommodation capacity.
- Breathable allows interior moisture vapour to escape.

## **TECHNICAL SPECIFICATION**

Pull off strength	>1 N/mm² / Mpa
Elongation % ASTM	Up To 80-100%
Positive pressure ASTM 1048	Up To 6 Bar
Negative pressure ASTM 1048	Up To 3 Bar
Crack Bridging ASTM 836	Up To 1 mm
Pot life	30 min @ 27°C

PACKAGING	COVERAGE	SHELF LIFE
Combo Pack (A+B): 5, 15, 60 kg FORM : Comp (A) Liquid & Comp (B) Powder, COLOUR : Grey	<ul> <li>Approx 100-120 sqft @ 2 coats</li> <li>(1 to 2mm dft thickness) per 15 kg box • 8 sq. Ft/ kg mix.</li> </ul>	12 months from the date of packing. Should be stored in cool & dry condition, keep away from direct sunlight.

#### **DIRECTION FOR USE**

# SURFACE PREPARATION



The object of the surface preparation is to achieve a clean sound surface with a good mechanical key. All substrates should be cleaned and free of dust, plaster, oil, paint, grease, and any other deleterious substances. Laitance should be removed by mechanical means. Masonry surfaces should be fully cured (minimum 28 days) prior to

application. Concrete substrates should be cured 28 days before 2 k waterproofing. Any edges must be rounded. Form coves with regular site-mixed mortar and round to a minimum radius of  $11/2^{"}$  (38 mm). Damaged or crack surface should be repaired by crack filling mortar.



AQUA FLEX W8 Waterproofing is supplied in precisely proportioned units ready for mixing,

I. Shake the liquid component. Transfer the entire quantity of liquid part A to a clean vessel. Aqua flex waterproofing shall be mixed with a low-speed stirrer (<500 RPM).

2. Start adding powder part B to liquid

part A into a vessel. Mix till smooth & homogeneous slurry without any lumps. Mix thoroughly for at least 3-4 minutes to the required consistency.

## **APPLICATION**

I. The surface must be dry & dampened (with no standing water). 2. AQUA FLEX W8 Waterproofing is applied on the positive side of the substrate. 3. Start applying the first coat of slurry with a stiff brush of 120-150 mm or broom, roller or flat trowel, maintaining the thickness of 1 mm. if required, embed with a fibreglass mesh. When the material is sticky, use a trowel to work the material up and trough the mesh until it is completely embedded. 4. Allow the 1st coat to dry for 4-6 hours. 5. Start applying the 2nd coat. The two-coat thickness should be a minimum of 2 mm. 6. 2nd coat should always be applied in the opposite direction to the 1st coat. 7. If the areas subjected to heavy hydrostatic pressure, apply another coat. 8. The product applied area should be protected from direct sunlight & to be damp cured by covering with damp hessian. After that, it should be protected by the overlapping of the screed.

## **PRECAUTION & LIMITATIONS**

• Do not add water at the site. • Mix the entire material at once. • Do not flood or overexpose the treated surface to water until it is completely cured. • When applying the material, the surface temperature should not be less than 10°C or more than 45°C. • Allow 14 days of curing before submersion.